

## 1 Products affected

Product hierarchy no. *				Part no.	SBU	Type / Description
SBU	PG	PUG	Type			
90	004	001	0000001000	See list	Voltage selector	SWP
90	004	004	0000001008	See list	Voltage selector	SWM1 (Panel)
90	004	005	0000001005	See list	Voltage selector	SWZ1 (Panel)
90	004	005	0000001012	See list	Voltage selector	SWA1 (Panel)
90	004	010	0000001009	See list	Voltage selector	SWM2 (Print)
90	004	011	0000001006	See list	Voltage selector	SWZ2 (Print)
90	004	011	0000001013	See list	Voltage selector	SWA2 (Print)

\*SBU (2-digit) / PG (3-digit) / PUG (3-digit) / Type (10-digit)

## 2 Type of change



- Modified label
- Improved identification product configuration code on the label

## 3 Detailed description of change

All product types listed in section 1 receive a new label layout.

To better visualize the changes, we have used colors and numbers to cluster information into the following sections (The colors and white numbers are not part of the new label layout):

<b>Product identification section:</b> To improve readability, we clustered all the information concerning product identification in this group. To increase clarity, we introduce our product configuration code into this area.	1
<b>Product conformity section:</b> Identical information was slightly rearranged.	2
<b>Product logistics section:</b> Label names changed. Information was slightly rearranged.	3
<b>Product approval section:</b> Identical information was slightly rearranged.	4
<b>Interruption ratings section:</b> Identical information was slightly rearranged.	5
<b>Origin information section:</b> Label for Factory Code was added. Information was slightly rearranged.	6

Old label	New label
 <p>The old label layout includes: 1. P/N 0033.4604; 2. SCHURTER AG CH-6002 Luzern; 3. QTY 100; 4. ST 6 CoO: CZ; 5. SWA Voltage selector switches; 6. 6.3A / 250VAC.</p>	 <p>The new label layout includes: 1. P/N 0033.4604 Type SWA2 (Print); 2. SCHURTER AG CH-6002 Luzern; 3. Qty 100; 4. Date Code 2110; 5. SWA2 115;230 SWA2-1229-00; 6. Fc ST CoO CZ.</p>

## 4 Reason of change

We modernize our label printing process to increase standardization and harmonize processes throughout all SCHURTER factory locations.

Product Change Notification					Global Labeling Ph. 3 Voltage Selector		
owner	creation date	release date	released by	change order no	rev	page	D10-056-053
vetersa	12.03.2021	15.03.2021	haeckima	2021676	A	1 of 2	

## 5 Release date

Packaging labels will be changed earliest in week 15/2021 (Date code 2115 or higher on the label).

## 6 Impact of change and recommended action

Form	No	
Fit	No	
Function	No	
Manufacturing	No	
Label	Yes	No actions required since bar code & 2D-code are not affected by the change.
Packaging	No	

## 7 Reference Documents / Attachments

Kind of document	Remarks
List of affected articles	

Product Change Notification					Global Labeling Ph. 3 Voltage Selector		
owner	creation date	release date	released by	change order no	rev	page	D10-056-053
vettersa	12.03.2021	15.03.2021	haeckima	2021676	A	2 of 2	

## Product Information Section

Part Number	Old Label Information		New Label Information		
P/N	Type	Description	Type	Short Text	Configuration Code
0033.1101	SWP	Voltage selector switches	SWP	SWP 110V;125V;145V;160V;220V;250V	SWP-374043-444649-00
0033.1104	SWP	Voltage selector switches	SWP	SWP unmarked	SWP-000000-000000-00
0033.1108	SWP	Voltage selector switches	SWP	SWP 100V;115V;127V;_;;220V;240V	SWP-363841-004648-00
0033.1109	SWP	Voltage selector switches	SWP	SWP 100V;115V;120V;220V;240V;_	SWP-363839-464800-00
0033.1110	SWP	Voltage selector switches	SWP	SWP 100V;115V;200V;220V;230V;240V	SWP-363845-464748-01
0033.1113	SWP	Voltage selector switches	SWP	SWP 100V;115V;125V;200V;220V;240V	SWP-363840-454648-00
0033.1118	SWP	Voltage selector switches	SWP	SWP _;100V;115V;220V;240V;_	SWP-003638-464800-00
0033.1119	SWP	Voltage selector switches	SWP	SWP 100V;110V;120V;200V;220V;240V	SWP-363739-454648-01
0033.1120	SWP	Voltage selector switches	SWP	SWP 100V;110V;220V;240V;_;	SWP-363746-480000-00
0033.1125	SWP	Voltage selector switches	SWP	SWP 100V;115V;130V;200V;230V;)	SWP-363842-454765-01
0033.1127	SWP	Voltage selector switches	SWP	SWP 100V;120V;200V;220V;230V;240V	SWP-363945-464748-00
0033.1130	SWP	Voltage selector switches	SWP	SWP 100V;110V;120V;125V;230V;240V	SWP-363739-404748-00
0033.1133	SWP	Voltage selector switches	SWP	SWP 40hm;80hm;160hm;_;;_;	SWP-505152-000000-00
0033.1134	SWP	Voltage selector switches	SWP	SWP 110V;220V;230V;_;;_;	SWP-374647-000000-00
0033.1136	SWP	Voltage selector switches	SWP	SWP 100;120;200;208;230;0	SWP-091422-232901-00
0033.1137	SWP	Voltage selector switches	SWP	SWP 100;115;230;240;_;;_;	SWP-091229-310000-00
0033.1140	SWP	Voltage selector switches	SWP	SWP 1;2;3;4;5;0	SWP-020304-050601-00
0033.1143	SWP	Voltage selector switches	SWP	SWP 100V;120V;230V;_;;_;	SWP-363947-000000-01
0033.1146	SWP	Voltage selector switches	SWP	SWP 80hm;160hm;100V;_;;_;	SWP-515236-000000-01
0033.3501	SWZ	Voltage selector switches	SWZ1 (Panel)	SWZ1 150;220;130;260;110;240	SWZ1-212717-331131-00
0033.3502	SWZ	Voltage selector switches	SWZ1 (Panel)	SWZ1 _;220;120;240;110;_	SWZ1-002714-311100-00
0033.3503	SWZ	Voltage selector switches	SWZ1 (Panel)	SWZ1 _;115;230;_;;_;	SWZ1-001229-000000-00
0033.3504	SWZ	Voltage selector switches	SWZ1 (Panel)	SWZ1 130;220;120;240;110;230	SWZ1-172714-311129-00
0033.3505	SWZ	Voltage selector switches	SWZ1 (Panel)	SWZ1 140;200;120;240;100;220	SWZ1-192214-310927-00
0033.3510	SWZ	Voltage selector switches	SWZ1 (Panel)	SWZ1 127;200;115;240;100;220	SWZ1-162212-310927-00
0033.3514	SWZ	Voltage selector switches	SWZ1 (Panel)	SWZ1 unmarked	SWZ1-000000-000000-00
0033.3518	SWZ	Voltage selector switches	SWZ1 (Panel)	SWZ1 _;220;130;_;;110;240	SWZ1-002717-001131-00
0033.3522	SWZ	Voltage selector switches	SWZ1 (Panel)	SWZ1 _;;_;;110;220;_;;_;	SWZ1-000011-270000-00
0033.3527	SWZ	Voltage selector switches	SWZ1 (Panel)	SWZ1 0;220;120;0;100;230-240	SWZ1-012714-010958-00
0033.3530	SWZ	Voltage selector switches	SWZ1 (Panel)	SWZ1 100;240;_;;220;120;_	SWZ1-093100-271400-00
0033.3531	SWZ	Voltage selector switches	SWZ1 (Panel)	SWZ1 _;200;115;240;100;220	SWZ1-002212-310927-01
0033.3532	SWZ	Voltage selector switches	SWZ1 (Panel)	SWZ1 _;127;200;115;230;100	SWZ1-001622-122909-01
0033.3539	SWZ	Voltage selector switches	SWZ1 (Panel)	SWZ1 130;200;115;230;100;215	SWZ1-172212-290925-00
0033.3547	SWZ	Voltage selector switches	SWZ1 (Panel)	SWZ1 _;200;120;240;100;_	SWZ1-002214-310900-00

0033.3549	SWZ	Voltage selector switches	SWZ1 (Panel)	SWZ1 100;0;117;220;100;240	SWZ1-090113-270931-00
0033.3551	SWZ	Voltage selector switches	SWZ1 (Panel)	SWZ1 134;200;117;234;100;217	SWZ1-182213-300926-01
0033.3553	SWZ	Voltage selector switches	SWZ1 (Panel)	SWZ1 140;200;120;240;100;230	SWZ1-192214-310929-00
0033.3555	SWZ	Voltage selector switches	SWZ1 (Panel)	SWZ1 _;_;120;240;100;220	SWZ1-000014-310927-00
0033.3558	SWZ	Voltage selector switches	SWZ1 (Panel)	SWZ1 140;200;120;230-240;100;220-230	SWZ1-192214-580956-00
0033.3560	SWZ	Voltage selector switches	SWZ1 (Panel)	SWZ1 127;220;115;240;110;230	SWZ1-162712-311129-00
0033.3563	SWZ	Voltage selector switches	SWZ1 (Panel)	SWZ1 _;240;230;220;200;_	SWZ1-003129-272200-01
0033.3801	SWZ	Voltage selector switches	SWZ2 (Print)	SWZ1 150;220;130;260;110;240	SWZ1-212717-331131-00
0033.3802	SWZ	Voltage selector switches	SWZ2 (Print)	SWZ2 130;220;120;240;110;230	SWZ2-172714-311129-00
0033.3803	SWZ	Voltage selector switches	SWZ2 (Print)	SWZ2 134;200;117;234;100;217	SWZ2-182213-300926-01
0033.3804	SWZ	Voltage selector switches	SWZ2 (Print)	SWZ2 127;200;115;240;110;220	SWZ2-162212-311127-01
0033.3805	SWZ	Voltage selector switches	SWZ2 (Print)	SWZ2 140;200;120;240;100;220	SWZ2-192214-310927-00
0033.3809	SWZ	Voltage selector switches	SWZ2 (Print)	SWZ2 127;spec.;spec.;spec.;100;220	SWZ2-167877-800927-01
0033.3812	SWZ	Voltage selector switches	SWZ2 (Print)	SWZ2 100;240;-;220;120;-	SWZ2-093164-271464-00
0033.3814	SWZ	Voltage selector switches	SWZ2 (Print)	SWZ2 unmarked	SWZ2-000000-000000-00
0033.3815	SWZ	Voltage selector switches	SWZ2 (Print)	SWZ2 _;_;120;220;100;240	SWZ2-000014-270931-01
0033.3819	SWZ	Voltage selector switches	SWZ2 (Print)	SWZ2 _;220;_;_;110;240	SWZ2-002700-001131-00
0033.3833	SWZ	Voltage selector switches	SWZ2 (Print)	SWZ2 145;210;125;250;105;230	SWZ2-202415-321029-00
0033.3845	SWZ	Voltage selector switches	SWZ2 (Print)	SWZ2 _;_;120;240;100;230	SWZ2-000014-310929-01
0033.3846	SWZ	Voltage selector switches	SWZ2 (Print)	SWZ2 120;220;115;230;110;225	SWZ2-142712-291128-00
0033.3847	SWZ	Voltage selector switches	SWZ2 (Print)	SWZ2 _;200;120;240;100;220	SWZ2-002214-310927-01
0033.3850	SWZ	Voltage selector switches	SWZ2 (Print)	SWZ2 _;_;_;240;100;120	SWZ2-000000-310914-01
0033.4001	SWM	Voltage selector switches	SWM1 (Panel)	SWM1 110;150;220	SWM1-112127-00
0033.4002	SWM	Voltage selector switches	SWM1 (Panel)	SWM1 110;220;240	SWM1-112731-00
0033.4003	SWM	Voltage selector switches	SWM1 (Panel)	SWM1 220;240;_	SWM1-273100-00
0033.4004	SWM	Voltage selector switches	SWM1 (Panel)	SWM1 200;220;240	SWM1-222731-00
0033.4006	SWM	Voltage selector switches	SWM1 (Panel)	SWM1 220;240;250	SWM1-273132-00
0033.4008	SWM	Voltage selector switches	SWM1 (Panel)	SWM1 100;115;230	SWM1-091229-00
0033.4011	SWM	Voltage selector switches	SWM1 (Panel)	SWM1 220;230;240	SWM1-272931-00
0033.4013	SWM	Voltage selector switches	SWM1 (Panel)	SWM1 _;120;240	SWM1-001431-01
0033.4014	SWM	Voltage selector switches	SWM1 (Panel)	SWM1 unmarked	SWM1-000000-00
0033.4019	SWM	Voltage selector switches	SWM1 (Panel)	SWM1 115;220;240	SWM1-122731-00
0033.4022	SWM	Voltage selector switches	SWM1 (Panel)	SWM1 200;210;220	SWM1-222427-01
0033.4028	SWM	Voltage selector switches	SWM1 (Panel)	SWM1 220V;230V;240V	SWM1-464748-00
0033.4029	SWM	Voltage selector switches	SWM1 (Panel)	SWM1 LOW;MED;HI	SWM1-727369-01
0033.4032	SWM	Voltage selector switches	SWM1 (Panel)	SWM1 4;8;16	SWM1-050708-00
0033.4036	SWM	Voltage selector switches	SWM1 (Panel)	SWM1 o;o;o	SWM1-666666-01
0033.4040	SWM	Voltage selector switches	SWM1 (Panel)	SWM1 100;110;230	SWM1-091129-00

0033.4044	SWM	Voltage selector switches	SWM1 (Panel)	SWM1 115;0;230	SWM1-120129-00
0033.4049	SWM	Voltage selector switches	SWM1 (Panel)	SWM1 230;240;250	SWM1-293132-00
0033.4055	SWM	Voltage selector switches	SWM1 (Panel)	SWM1 115V;230V;240V	SWM1-384748-00
0033.4056	SWM	Voltage selector switches	SWM1 (Panel)	SWM1 1;2;3	SWM1-020304-00
0033.4057	SWM	Voltage selector switches	SWM1 (Panel)	SWM1 100;120;230-240	SWM1-091458-00
0033.4061	SWM	Voltage selector switches	SWM1 (Panel)	SWM1 230;115;0	SWM1-291201-01
0033.4062	SWM	Voltage selector switches	SWM1 (Panel)	SWM1 110;_;230	SWM1-110029-00
0033.4065	SWM	Voltage selector switches	SWM1 (Panel)	SWM1 100;120;230	SWM1-091429-01
0033.4066	SWM	Voltage selector switches	SWM1 (Panel)	SWM1 +2;0;-2	SWM1-630162-01
0033.4067	SWM	Voltage selector switches	SWM1 (Panel)	SWM1 0;1;2	SWM1-010203-01
0033.4069	SWM	Voltage selector switches	SWM1 (Panel)	SWM1 100-120;127;220-240	SWM1-551657-01
0033.4201	SWM	Voltage selector switches	SWM2 (Print)	SWM1 110;150;220	SWM1-112127-01
0033.4202	SWM	Voltage selector switches	SWM2 (Print)	SWM1 110;220;240	SWM1-112731-01
0033.4208	SWM	Voltage selector switches	SWM2 (Print)	SWM2 100;115;230	SWM2-091229-00
0033.4214	SWM	Voltage selector switches	SWM2 (Print)	SWM2 unmarked	SWM2-000000-00
0033.4241	SWM	Voltage selector switches	SWM2 (Print)	SWM2 100V;120V;220V	SWM2-363946-01
0033.4252	SWM	Voltage selector switches	SWM2 (Print)	SWM2 spec.;127;spec.	SWM2-791676-01
0033.4254	SWM	Voltage selector switches	SWM2 (Print)	SWM2 230;0;200	SWM2-290122-01
0033.4256	SWM	Voltage selector switches	SWM2 (Print)	SWM2 1;2;3	SWM2-020304-01
0033.4259	SWM	Voltage selector switches	SWM2 (Print)	SWM2 115;200;230	SWM2-122229-00
0033.4260	SWM	Voltage selector switches	SWM2 (Print)	SWM2 230;_;115	SWM2-290012-01
0033.4501	SWA	Voltage selector switches	SWA1 (Panel)	SWA1 110;220	SWA1-1127-00
0033.4502	SWA	Voltage selector switches	SWA1 (Panel)	SWA1 115;220	SWA1-1227-00
0033.4503	SWA	Voltage selector switches	SWA1 (Panel)	SWA1 120;240	SWA1-1431-00
0033.4504	SWA	Voltage selector switches	SWA1 (Panel)	SWA1 115;230	SWA1-1229-00
0033.4505	SWA	Voltage selector switches	SWA1 (Panel)	SWA1 220;240	SWA1-2731-01
0033.4508	SWA	Voltage selector switches	SWA1 (Panel)	SWA1 50 Hz;60 Hz	SWA1-5354-00
0033.4509	SWA	Voltage selector switches	SWA1 (Panel)	SWA1 110;240	SWA1-1131-01
0033.4510	SWA	Voltage selector switches	SWA1 (Panel)	SWA1 230;240	SWA1-2931-01
0033.4512	SWA	Voltage selector switches	SWA1 (Panel)	SWA1 115;220/240	SWA1-1260-01
0033.4513	SWA	Voltage selector switches	SWA1 (Panel)	SWA1 LO;HI	SWA1-7069-00
0033.4514	SWA	Voltage selector switches	SWA1 (Panel)	SWA1 unmarked	SWA1-0000-00
0033.4515	SWA	Voltage selector switches	SWA1 (Panel)	SWA1 120;230	SWA1-1429-01
0033.4518	SWA	Voltage selector switches	SWA1 (Panel)	SWA1 0;1	SWA1-0102-00
0033.4521	SWA	Voltage selector switches	SWA1 (Panel)	SWA1 A;B	SWA1-6768-00
0033.4522	SWA	Voltage selector switches	SWA1 (Panel)	SWA1 1;2	SWA1-0203-01
0033.4524	SWA	Voltage selector switches	SWA1 (Panel)	SWA1 Test;RUN	SWA1-7574-00
0033.4526	SWA	Voltage selector switches	SWA1 (Panel)	SWA1 HI;LO	SWA1-6970-01

0033.4527	SWA	Voltage selector switches	SWA1 (Panel)	SWA1 HI;LO LO	SWA1-6971-01
0033.4601	SWA	Voltage selector switches	SWA2 (Print)	SWA2 110;220	SWA2-1127-00
0033.4603	SWA	Voltage selector switches	SWA2 (Print)	SWA2 120;240	SWA2-1431-00
0033.4604	SWA	Voltage selector switches	SWA2 (Print)	SWA2 115;230	SWA2-1229-00
0033.4607	SWA	Voltage selector switches	SWA2 (Print)	SWA2 110/120V;220/240V	SWA2-5961-01
0033.4610	SWA	Voltage selector switches	SWA2 (Print)	SWA2 230;240	SWA2-2931-00
0033.4614	SWA	Voltage selector switches	SWA2 (Print)	SWA2 unmarked	SWA2-0000-00
0033.4615	SWA	Voltage selector switches	SWA2 (Print)	SWA2 120;230	SWA2-1429-00
0033.4619	SWA	Voltage selector switches	SWA2 (Print)	SWA2 100;230	SWA2-0929-00
0033.4623	SWA	Voltage selector switches	SWA2 (Print)	SWA2 24V;48V	SWA2-3435-01